

DMX Chart (1/3/4/6/7/16-Channel Modes)

Channel Mode						Function
1	3	4	6	7	16	
	1	1	1	1	1	Master Dimmer (0-100%)
-----	-----	-----	2	2	2	Segment 1-3 Intensity (0-100%)
-----	-----	-----	3	3	3	Segment 4-6 Intensity (0-100%)
-----	-----	-----	4	4	4	Segment 7-9 Intensity (0-100%)
	2	2	5	5	5	Flash duration (0-full on)
1	3	3	6	6	6	Strobe rate (0-30Hz)
-----	-----	4		7	7	Built-In Effects
-----	-----	-----	-----	-----	8	Segment 1 Intensity (0-100%)
-----	-----	-----	-----	-----	9	Segment 2 Intensity (0-100%)
-----	-----	-----	-----	-----	10	Segment 3 Intensity (0-100%)
-----	-----	-----	-----	-----	11	Segment 4 Intensity (0-100%)
-----	-----	-----	-----	-----	12	Segment 5 Intensity (0-100%)
-----	-----	-----	-----	-----	13	Segment 6 Intensity (0-100%)
-----	-----	-----	-----	-----	14	Segment 7 Intensity (0-100%)
-----	-----	-----	-----	-----	15	Segment 8 Intensity (0-100%)
-----	-----	-----	-----	-----	16	Segment 9 Intensity (0-100%)